



VDL SYNERGY SDD 141-510 -91 POSTI		
	<b>corridoio piano inferiore</b>	
1	2	1
2		
5	6	5
6		
9	10	9
10		
13	14	13
14		
17	18	17
18		
19	20	19
20		
21	22	21
22		
	25	24
24		
25		

<b>PORTA ANTERIORE</b>	
SCALA	
3	4
8	7
12	11
16	15
<b>PEDANA DISABILE</b>	
<b>PORTA POSTERIORE</b>	
SCALA	

30	31	30	<b>corridoio piano superiore</b>
31			
32	33	32	
33			
36	37	36	
37			
40	41	40	
41			
44	45	44	
45			
48	49	48	
49			
52	53	52	
53			
56	57	56	
57			
60	61	60	
61			
64	65	64	
65			
66	67	66	
67			
70	71	70	
71			
74	75	74	
75			
78	79	78	
79			
82	83	82	
83			
86	87	86	
87			
91	92	91	90
92			

SCALA	
35	34
39	38
43	42
47	46
51	50
55	54
59	58
63	62
SCALA	
69	68
73	72
77	76
81	80
85	84
89	88